Radio / CD

Miami Beach CD51
Tampa Bay CD51

Operating instructions

BLAUPUNKT

Open here

Ouvrir s.v.p.

Por favor, abrir

Favor abrir


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
BLAUPUNKT
MIX
MENU
OK

CONTROLS

1. button – to unlock the removable control panel (release panel)
2. Volume control
3. Button – switches the unit on/off, volume mute
4. **FM** button – selects the radio mode source,
   selects the FM memory levels
5. **AM** button – selects the radio mode source,
   selects the AM frequency range
6. Display
7. button – displays the time,
   DIS – changes the display content
8. **MENU** button – opens the basic settings menu
9. button – opens the flip-release panel
10. Arrow buttons
11. **OK** button – confirms menu entries and starts the scan function
12. **X-BASS** button – to set the X-Bass feature
13. **AUDIO** button (audio) – adjusts the bass, treble, balance and fader
14. Keys **1** - **6**
15. **TS** button – starts the Travelstore function
16. **CD•C** button – to switch between CD, CD changer (if connected) and AUX sources

TABLE OF CONTENTS

Notes and accessories 6
Road safety 6
Installation 6
Accessories 6
International telephone information ... 6

Removable control panel 7

Switching on/off 8

Adjusting the volume 9
Setting the power-on volume 9
Instantaneous volume reduction (mute) 9
Telephone audio / navigation audio .. 9
Setting the volume of the confirmation beep 10

Radio mode 11
Switching to radio mode 11
Selecting the frequency range / memory 11
Tuning into a station 11
Storing stations 11
Storing stations automatically (Travelstore) 12
Listening to preset stations 12
Scanning receivable stations (SCAN) 12
Setting the scantime 12
Tuner configuration 12
Setting the display 13

CD mode 13
Switching to CD mode 13
Selecting tracks 14
Quick track selection 14
Fast searching (audible) 14
Random play (MIX) 14
Scanning tracks (SCAN) 14
Repeating tracks (REPEAT) 14
Pausing playback (PAUSE) 14
Changing the display 15
Ejecting a CD 15

CD changer mode 15
Switching to CD changer mode 15
Selecting a CD 15
Selecting tracks 15
Quick track selection 15
Fast searching (audible) 15
Changing the display 16
Repeating individual tracks or whole CDs (REPEAT) 16
Random play (MIX) 16
Scanning all tracks on all CDs (SCAN) 16
Pausing playback (PAUSE) 17

CLOCK - Time 17

Sound and volume distribution settings .. 19
Adjusting the bass settings 19
Adjusting the treble settings 19
Setting the left/right volume distribution (balance) 19
Setting the front/back volume distribution (fader) 19

X-BASS 20

Setting the spectrometer 20

External audio sources 21

Specifications 21

Guarantee 22

Installation instructions 80

NOTES AND ACCESSORIES

Thank you for deciding to purchase a Blaupunkt product. We hope you enjoy using this new piece of equipment.
Before using the device for the first time, please read these instructions carefully. The Blaupunkt editors are constantly working on making the operating instructions clearer and easier to understand. However, if you still have any questions on how to operate the unit please contact your dealer or the telephone hotline for your country. You will find the hotline telephone numbers printed at the back of this booklet.

Road safety

⚠ Road safety has absolute priority. Only operate your car radio if the road and traffic conditions allow you to do so. Familiarise yourself with the unit before setting off on your journey.
You should always be able to hear police, fire and ambulance sirens from afar. For this reason, set the volume of whatever you are listening to to a reasonable level.

Installation

If you want to install your car radio yourself, please read the installation and connection instructions that follow these operating instructions.

Accessories

Only use accessories approved by Blaupunkt.

Remote control

The optional RC08 or RC10 remote controls allow you to safely and conveniently access the most important functions of your car radio from your steering wheel.
The RC 06 H remote control is supplied with the Tampa Bay CD51.

Amplifier

All Blaupunkt amplifiers can be used.

CD changer

You can connect the following Blaupunkt CD changers:
CDC A 06, CDC A 08, CDC A 072 and IDC A 09.
You can also connect the CDC A 05 and CDC A 071 CD changers by using an adapter cable (Blaupunkt no.: 7 607 889 093).

International telephone information

If you have any questions regarding the operation of your car radio or if you require further information, please do not hesitate to call us!
The information hotline numbers are printed on the last page of these instructions.

Removable control panel

Theft protection

As a way of protecting your car radio against theft, the unit is equipped with a removable control panel (flip-release panel). Without this control panel, the car radio is worthless to a thief.
Protect your car radio against theft by taking the control panel with you every time you leave your vehicle. Do not leave the control panel in your vehicle - not even in a hiding place.
The control panel has been designed to be easy to use.

Note:

- Never drop the control panel.
- Never expose the control panel to direct sunlight or other heat sources.
- Store the control panel in the supplied case.
- Avoid making direct skin contact with the control panel's contacts. If necessary, clean the contacts with a lint-free cloth soaked in cleaning spirits.

Removing the control panel



➪ Press the [button (1).

The control panel locking mechanism opens.

➪ First, pull the control panel straight off the unit and then out towards the left.

- The unit switches off after the control panel is removed.
- All the current settings are saved.
- Any CD already inserted in the unit remains there.

Attaching the control panel

➪ Slide the control panel from left to right into the unit's panel locking mechanism.

➪ Press the left-hand edge of the control panel into the unit until it clicks into place.



Note:

- When attaching the control panel, make sure you do not press the display.

If the unit was still switched on when you removed the control panel, the unit will automatically switch on with the last settings activated (i.e. radio, CD, CD changer, or AUX) when the panel is replaced.

Switching on/off

There are various ways of switching the unit on/off:

Switching on/off using the vehicle ignition

If the unit is correctly connected to the vehicle's ignition and it was not switched off using button (3), it will switch on/off simultaneously with the ignition.

You can switch the unit on even if the ignition is off:

➪ To do so, press button (3).

Note:

- To protect the vehicle battery, the unit will switch off automatically after one hour if the ignition is off.

Switching on/off using the removable control panel

➪ Remove the control panel.

The unit switches off.

➪ Attach the control panel again.

The unit switches on. The last settings (radio, CD, CD changer or AUX) will be reactivated.

Switching on/off using button (3)

➪ To switch the unit on, press button (3).

➪ To switch the unit off, press button (3) for longer than two seconds.

The unit switches off.

Switching on by inserting a CD

If the unit is switched off and there is no CD inserted in the drive,

➪ press the ⏏ button (9).

The flip-release panel opens.

➪ Gently insert the CD with the printed side uppermost into the drive until you feel some resistance.

The CD will be drawn automatically into the drive.
You must not hinder or assist the drive as it draws in the CD.

➪ Gently close the control panel whilst exerting a little pressure until you feel it click into place.

The unit switches on. CD playback begins.

Adjusting the volume

The volume can be adjusted in steps from 0 (off) to 66 (maximum).

- ⇨ To increase the volume, turn the volume control (2) to the right.
- ⇨ To decrease the volume, turn the volume control (2) to the left.

Setting the power-on volume

You can set the unit's default power-on volume.

- ⇨ Press the **MENU** button (8).
- ⇨ Keep pressing the ∨ or ∧ button (10) until "ON VOLUME" appears in the display.
- ⇨ Set the power-on volume using the < and > buttons (10).

If you change the setting to "0", the power-on volume will be the same as the volume level that was set before the unit was last switched off.

Note:

- To protect your hearing, the power-on volume is limited to a value of "38". If the volume level was higher when the unit was switched off, the volume will be reset to "38" when the unit is switched on again.

When you have finished making your changes,

- ⇨ press the **MENU** button (8) or **OK** (11) twice.

Instantaneous volume reduction (mute)

This feature allows you to instantaneously reduce (mute) the volume to a level preset by you.

- ⇨ Briefly press button (3).

"MUTE" appears in the display.

Setting the mute level

You can set the unit's mute volume level.

- ⇨ Press the **MENU** button (8).
- ⇨ Keep pressing the ∨ or ∧ button (10) until "MUTE LEVEL" appears in the display.
- ⇨ Set the mute level using the < and > buttons (10).

When you have finished making your changes,

- ⇨ press the **MENU** button (8) or **OK** (11) twice.

Telephone audio / navigation audio

If your car radio is connected to a mobile telephone or a navigation system, the unit's volume will be muted as soon as you "pick up" the telephone or as soon as a navigation announcement is made. The caller or voice output will then be heard over the car radio loudspeakers. In order for this to work, the mobile telephone or navigation system must be connected to the car radio in the manner described in the installation instructions.

ADJUSTING THE VOLUME

You can find out from your Blaupunkt dealer which navigation systems can be used with your car radio.

You can set the volume level at which telephone calls and the navigation voice output will first be heard.

- ⇨ Press the **MENU** button (8).
- ⇨ Keep pressing the ⋁ or ⋀ button (10) until “TEL/NAVI VOL” appears in the display.
- ⇨ Set the required volume using the < and > buttons (10).

When you have finished making your changes,

- ⇨ press the **MENU** button (8) or **OK** (11) twice.

Note:

- Using the volume control (2), you can directly adjust the volume of telephone calls and navigation voice output (whilst they are being heard).

Setting the volume of the confirmation beep

For some functions you will hear a confirmation beep if you keep a button pressed for longer than two seconds. For instance, after storing a radio station to a station button you will hear a confirmation beep. You can set the volume of this beep.

- ⇨ Press the **MENU** button (8).
- ⇨ Keep pressing the ⋁ or ⋀ button (10) until “BEEP” appears in the display.
- ⇨ Set the volume using the < and > buttons (10). “0” means beep off, “9” means maximum beep volume.

When you have finished making your changes,

- ⇨ press the **MENU** button (8) or **OK** (11).

Radio mode

Switching to radio mode

If you are in CD, CD changer or AUX mode,

➪ press the **FM** (4) / **AM** (5) button

or

➪ keep pressing the **CD•C** button (16) until “RADIO” appears in the display.

Selecting the frequency range / memory

This unit can receive programmes broadcast over the FM and AM frequency ranges. There are three preset memory levels for the FM range and one for the AM range. Six stations can be stored on each memory level.

Selecting the FM memory level

➪ Press the **FM** button (4) to switch between the FM memory levels (FM1, FM2 and FMT).

Selecting the AM frequency range

➪ Press the **AM** button (5) to select the AM frequency range.

Tuning into a station

There are various ways of tuning into a station.

Automatic seek tuning

➪ Press the ⩒ or ⩓ button (10).

The unit tunes into the next receivable station.

Setting the sensitivity for station seek tuning

You can configure the radio to only tune into stations with a strong reception or to also tune into those with a weak reception.

➪ Press the **MENU** button (8).

➪ Keep pressing the ⩒ or ⩓ button (10) until “SENS HI” or “SENS LO” appears in the display.

“SENS HI” means that the tuner is highly sensitive. “SENS LO” means it is set to the lowest sensitivity setting. If “SENS LO” is selected, “lo” lights up in the display.

➪ Set the required sensitivity using the < and > buttons (10).

When you have finished making your changes,

➪ press the **MENU** button (8) or **OK** (11).

Tuning into stations manually

You can also tune into stations manually.

➪ Press the < or > button (10).

Storing stations

Storing stations manually

➪ Select the required memory level (FM1, FM2 or FMT) or the AM frequency range.

➪ Tune into the station.

➪ Press one of the station buttons **1-6** (14) for longer than one second to store the station to that button.

Storing stations automatically (Travelstore)

You can automatically store the six stations with the strongest reception in the region. The stations are stored in the FMT or AM memory depending on the selected frequency range.

Note:

- Stations that were previously stored in this memory are deleted in the process.

➪ Briefly press the **TS** button (15).

The station storing procedure begins. "TRAVEL-STORE" appears in the display. After the process is completed, the station that is stored in location **1** of the respective memory level will be played.

Listening to preset stations

➪ Select the memory level on which the station was stored.

➪ Press the preset station button **1-6** (14) of the station you want to listen to.

Scanning receivable stations (SCAN)

You can briefly play all the receivable stations. You can set the scanning time to between 5 and 30 seconds in the menu.

Starting SCAN

➪ Keep the **OK** button (11) pressed until the scan process starts.

"SCAN" appears briefly in the display followed by the current frequency (which flashes).

Stopping SCAN and continuing listening to a station

➪ Press the **OK** button (11).

Scanning is stopped and the station that was tuned into last will remain active.

Setting the scantime

➪ Press the **MENU** button (8).

➪ Keep pressing the ⩒ or ⩓ button (10) until "SCANTIME" appears in the display.

➪ Set the required scantime using the < and > buttons (10).

When you have finished making your changes,

➪ press the **MENU** button (8) or **OK** (11) twice.

Note:

- The set scantime also applies to scanning in CD and CD changer mode.

Tuner configuration

This unit is equipped with a multiband tuner. The tuner can be configured to suit the requirements that are specific to various countries. The countries/regions available are: America, Europe, Asia and Thailand. The tuner will only function optimally if it is configured for the country/region in which the unit is being operated.

Configuring the tuner

➪ Press the **MENU** button (8).

➪ Keep pressing the ⩒ or ⩓ button (10) until "FM TUNER" appears in the display.

➪ Press the < or > button (10) to set the country/region.

When you have finished making your changes,

➪ press the **MENU** button (8) or **OK** (11) twice.

Note:

- Once you have configured the tuner, the unit will switch to radio mode and tune into the preset frequency 87.5 MHz

Setting the display

In radio mode, you have the option of continuously displaying the time or continuously displaying the frequency.

➪ Keep the ◷ / **DIS** button (7) pressed until the required display appears.

CD mode

You can use this unit to play standard CDs with a diameter of 5 inches.

⚠ Risk of damage to the CD drive!
CD singles with a diameter of 3 inches and contoured CDs (shape CDs) are not suitable for playback in this unit.
We accept no liability for any damage to the CD drive that may occur as a result of the use of unsuitable CDs.

Switching to CD mode

- If there is no CD inserted in the drive,

➪ press the ◺ button (9).

The flip-release panel opens.

➪ Gently insert the CD with the printed side uppermost into the drive until you feel some resistance.

The CD is drawn into the drive automatically.
You must not hinder or assist the drive as it draws in the CD.

➪ Gently close the control panel whilst exerting a little pressure until you feel it click into place.

CD playback begins.

- If a CD is already inserted in the drive.

➪ Keep pressing the **CD•C** button (16) until “CD” appears in the display.

Playback begins from the point at which it was last interrupted.

Selecting tracks

➪ Press one of the arrow buttons (10) to select the next or previous track.

If you press the ⏮ or ⏮ button (10) once, the current track will be played again from the beginning.

Quick track selection

To quickly select tracks backwards or forwards,

➪ keep one of the ⏮ or ⏭ buttons (10) pressed until fast-reverse / fast-forward track selection begins.

Fast searching (audible)

To fast search backwards or forwards,

➪ keep one of the ◀◀ ▶▶ buttons (10) pressed until fast reversing / fast forwarding begins.

Random play (MIX)

➪ Press button **5 MIX** (14).

"MIX CD" appears briefly in the display and the MIX symbol lights up. The next randomly selected track will then be played.

Stopping MIX

➪ Press button **5 MIX** (14) again.

"MIX OFF" appears briefly in the display and the MIX symbol disappears.

Scanning tracks (SCAN)

You can briefly play all the tracks on a CD.

➪ Press the **OK** button (11) for longer than two seconds. The next track will then be played briefly.

Note:

- You can set the scantime. For further details, please read the section entitled "Setting the scantime" in the "Radio mode" chapter.

Stopping SCAN and continuing playback

➪ To stop scanning, press the **OK** button (11).

The current track will then continue to be played.

Repeating tracks (REPEAT)

➪ If you want to repeat a track, press button **4 RPT** (14).

"REPEAT TRCK" appears briefly in the display and the RPT symbol lights up. The track is repeated until you deactivate RPT.

Cancelling repeat

➪ If you want to stop the repeat function, press button **4 RPT** (14) again.

"REPEAT OFF" appears briefly in the display and the RPT symbol disappears. Normal playback is then continued.

Pausing playback (PAUSE)

➪ Press button **3** ⏯ (14).

"PAUSE" appears in the display.

Cancelling pause

➪ Press button **3** ⏯ (14) while in pause mode.

Playback is continued.

Changing the display

➪ To switch between the track number and clock display / track number and playing time display, press the ◷ / **DIS** button (7) once or several times for longer than two seconds until the required display appears.

Ejecting a CD

➪ Press the ⏏ button (9).

The flip-release panel opens and the CD is ejected.

➪ Remove the CD and close the control panel.

CD changer mode

Note:

- Information on handling CDs, inserting CDs and operating the CD changer can be found in the operating instructions supplied with your CD changer.

Switching to CD changer mode

➪ Keep pressing the **CD•C** button (16) until “CHANGER” appears in the display.

Playback begins with the first CD that the CD changer detects.

Selecting a CD

➪ To move up/down from one CD to another, press the ∧ or ∨ button (10) once or several times.

Selecting tracks

➪ To move up/down from one track to another on the current CD, press the > or < button (10) once or several times.

Quick track selection

To quickly select tracks backwards or forwards,

➪ keep one of the ∨ or ∧ buttons (10) pressed until fast-reverse / fast-forward track selection begins.

Fast searching (audible)

To fast search backwards or forwards,

➪ keep one of the < > buttons (10) pressed until fast reversing / fast forwarding begins.

Changing the display

➪ To switch between the track number and clock display / track number and playing time display / CD number and track number display, press the ◷ / **DIS** button (7) once or several times for longer than two seconds until the required display appears.

Repeating individual tracks or whole CDs (REPEAT)

➪ If you wish to repeat the current track, briefly press button **4 RPT** (14).

"REPEAT TRCK" appears briefly and RPT lights up in the display.

➪ If you wish to repeat the current CD, press button **4 RPT** (14) again.

"REPEAT DISC" appears briefly and RPT lights up in the display.

Cancelling repeat

➪ If you want to stop the repeat function for the current track or CD, press button **4 RPT** (14) until "REPEAT OFF" appears briefly in the display and RPT disappears.

Random play (MIX)

➪ To play all the tracks on the current CD in random order, briefly press button **5 MIX** (14).

"MIX CD" appears briefly and MIX lights up in the display.

➪ To play the tracks on all the inserted CDs in random order, press button **5 MIX** (14) again.

"MIX ALL" appears briefly and MIX lights up in the display.

Note:

- In the case of the CDC A 08 and the IDC A 09, all the CDs in the changer are selected randomly. In the case of any other changer, all the tracks on one CD are played randomly before the next CD in the changer is played.

Stopping MIX

➪ Press button **5 MIX** (14) until "MIX OFF" appears briefly in the display and MIX disappears.

Scanning all tracks on all CDs (SCAN)

➪ To briefly play all the tracks on all inserted CDs in ascending order, press the **OK** button (11) for longer than two seconds.

"SCAN" appears in the display.

Stopping SCAN

➪ To stop scanning, briefly press the **OK** button (11).

The current track will then continue to be played.

Note:

- You can set the scantime. For further details, please read the section entitled "Setting the scantime" in the "Radio mode" chapter.

Pausing playback (PAUSE)

➪ Press button **3** ⏸ (14).

"PAUSE" appears in the display.

Cancelling pause

➪ Press button **3** ⏸ (14) while in pause mode.

Playback is continued.

CLOCK - Time

Briefly displaying the time

➪ To display the time, briefly press the ◷ / **DIS** button (7).

Setting the time

Setting the time manually

➪ To set the time, press the **MENU** button (8).

➪ Keep pressing the ∨ or ∧ button (10) until "CLOCKSET" appears in the display.

➪ Press the > button (10).

The time appears in the display. The minutes flash on and off and can be adjusted.

➪ Adjust the minutes using the ∧∨ buttons (10).

➪ Once you have set the minutes, press the < button (10). The hours start flashing.

➪ Adjust the hours using the ∧∨ buttons (10).

➪ Press the **MENU** button (8) or **OK** (11) twice.

Selecting 12/24-hour clock mode

➪ Press the **MENU** button (8).

"MENU" appears in the display.

➪ Keep pressing the ⋁ or ⋀ button (10) until "24 H MODE" or "12 H MODE" appears in the display.

➪ Press the < or > button (10) to switch between the modes.

When you have finished making your changes,

➪ press the **MENU** button (8) or **OK** (11).

Displaying the time continuously when the unit is off and the ignition is on

To display the time when the unit is off and the vehicle ignition is on,

➪ press the **MENU** button (8).

➪ Keep pressing the ⋁ or ⋀ button (10) until "CLK DISP OFF" or "CLK DISP ON" appears in the display.

➪ Press the < or > button (10) to switch between the ON/OFF settings.

When you have finished making your changes,

➪ press the **MENU** button (8) or **OK** (11).

Briefly displaying the time when the unit is switched off

To briefly display the time when the unit is off,

➪ press the ◷ / **DIS** button (7).

The time is displayed for eight seconds.

Sound and volume distribution settings

You can adjust the sound and volume distribution settings separately for each source (radio, CD, CD changer and AUX).

Adjusting the bass settings

- Press the **AUDIO** button (13).

"BASS" appears in the display.

- Press the ⩒ or ⩓ button (10) to adjust the bass.

When you have finished making your changes,

- press the **AUDIO** button (13).

Adjusting the treble settings

- Press the **AUDIO** button (13).

"BASS" appears in the display.

- Keep pressing the > button (10) until "TREBLE" appears in the display.
- Press the ⩒ or ⩓ button (10) to adjust the treble.

When you have finished making your changes,

- press the **AUDIO** button (13).

Setting the left/right volume distribution (balance)

- To set the left/right volume distribution (balance), press the **AUDIO** button (13).

"BASS" appears in the display.

- Keep pressing the > button (10) until "BALANCE" appears in the display.
- Press the ⩒ or ⩓ button (10) to adjust the balance (right/left).

When you have finished making your changes,

- press the **AUDIO** button (13).

Setting the front/back volume distribution (fader)

- To set the front/back volume distribution (fader), press the **AUDIO** button (13).

"BASS" appears in the display.

- Keep pressing the > button (10) until "FADER" appears in the display.
- Press the ⩒ or ⩓ button (10) to adjust the fader (front/back).

When you have finished making your changes,

- press the **AUDIO** button (13).

X-BASS

The X-BASS feature can be used to boost the bass at low volume levels.

Adjusting the X-BASS boost settings

The X-BASS boost can be set in steps from “X-BASS LOW” to “X-BASS MID” to “X-BASS HIGH”.

- Press the **X-BASS** button (12).
- Keep pressing the < or > button (10) until the required setting appears in the display.

When you have finished making your changes,

- press the **X-BASS** button (12).

Setting the spectrometer

The spectrometer (level display) briefly provides a symbolic display of the volume and the audio control settings whilst you are adjusting them.

When you are not changing any settings, the spectrometer displays the car radio’s output level.

You can set the type of spectrometer in the menu.

There are two types available.

Setting the spectrometer type

- Press the **MENU** button (8).

“MENU” appears in the display.

- Keep pressing the ⩒ or ⩓ button (10) until “EQ DISPLAY” appears in the display.
- Press the < or > button (10) to select “SPECTRUM 1”, “SPECTRUM 2” or “EQ DISP OFF.”

When you have finished making your changes,

- press the **MENU** button (8) or **OK** (11) twice.

External audio sources

Instead of connecting a CD changer, you can connect another audio source equipped with a line output. The audio source, for example, can be a portable CD player, MiniDisc player or MP3 player.
The AUX input must be activated in the menu.
If you want to connect an external audio source, you will need an adapter cable. You can obtain this adapter cable (BP no.: 7 607 897 093) from your authorised Blaupunkt dealer.

Switching the AUX input on/off

➪ Press the **MENU** button (8).

"MENU" appears in the display.

➪ Keep pressing the ⩒ or ⩓ button (10) until "AUX-IN-1 OFF" or "AUX-IN-1 ON" appears in the display.

➪ Press the < or > button (10) to switch AUX on/off.

When you have finished making your changes,

➪ press the **MENU** button (8) or **OK** (11).

Note:

- If the AUX input is switched on it can be selected by pressing the **CD•C** button (16).

Specifications

Amplifier

Output power: 4 x 25 watts sine in accordance with DIN 45 324 at 14.4 V
4 x 50 watts max. power

Tuner

Frequency ranges US:
FM: 87.5 – 107.9 MHz
AM: 530 – 1710 kHz

Frequency ranges Asia and Europe:
FM: 87.5 – 108 MHz
AM: 531 – 1602 kHz

Frequency ranges Thailand:
FM: 87.5 – 108 MHz
AM: 531 – 1629 kHz

FM mono sensitivity:
17 dbf

FM frequency response:
35 - 16,000 Hz

CD

Frequency response:
20 - 20,000 Hz

Pre-amp out

4 channels: 3 V

Input sensitivity

AUX input: 2 V / 6 kΩ
Tel./Navi input: 10 V/ 1 kΩ

Subject to changes!

Guarantee

The scope of the guarantee is orientated around the regulations in force within the country in which the unit was purchased.

If your unit develops a fault, please contact your dealer and present the purchase receipt.

If the statutory guarantee period in your country is less than 12 months, Blaupunkt will grant a 12-month manufacturer's guarantee. This guarantee does not cover damage due to wear, incorrect usage or commercial use.

If you wish to enforce a claim under the manufacturer's guarantee that is provided by Blaupunkt, please send the faulty unit together with the purchase receipt to the Blaupunkt customer service centre in your country. You can find out which address is closest to you by contacting the telephone hotline listed on the back page of this booklet. Blaupunkt retains the right to rectify defects or supply a replacement.

Service numbers / Numéros du service après-vente / Números de servicio / Número de serviço

Country:		Phone:	Fax:	WWW:
Germany	(D)	0180-5000225	05121-49 4002	http://www.blaupunkt.com
Austria	(A)	01-610 390	01-610 393 91	
Belgium	(B)	02-525 5454	02-525 5263	
Denmark	(DK)	44 898 360	44-898 644	
Finland	(FIN)	09-435 991	09-435 99236	
France	(F)	01-4010 7007	01-4010 7320	
Great Britain	(GB)	01-89583 8880	01-89583 8394	
Greece	(GR)	0800-550 6550	01-576 9473	
Ireland	(IRL)	01-4149400	01-4598830	
Italy	(I)	02-369 6331	02-369 6464	
Luxembourg	(L)	40 4078	40 2085	
Netherland	(NL)	023-565 6348	023-565 6331	
Norway	(N)	66-817 000	66-817 157	
Portugal	(P)	01-2185 00144	01-2185 11111	
Spain	(E)	902-120234	916-467952	
Sweden	(S)	08-7501500	08-7501810	
Switzerland	(CH)	01-8471644	01-8471650	
Czech. Rep.	(CZ)	02-6130 0441	02-6130 0514	
Hungary	(H)	01-333 9575	01-324 8756	
Poland	(PL)	0800-118922	022-8771260	
Turkey	(TR)	0212-3350677	0212-3460040	
USA	(USA)	800-2662528	708-6817188	
Brasil (Mercosur)	(BR)	+55-19 3745 2769	+55-19 3745 2773	
Malaysia (Asia Pacific)	(MAL)	+604-6382 474	+604-6413 640	

Blaupunkt GmbH

07/01

K7/VKD 8 622 402 730